

# 143 Saxophonständer

- für Es-Alt und B-Tenor
- klein zusammenlegbar
- Bügel für Schallbecher einstellbar
- nachrüstbar mit Kegelhalter für weitere Instrumente

## Montage- und Betriebsanleitung

### Abb. A

- FüÙe auseinanderklappen
- Instrumentenhalterrohr 2 in den Sockel 1 stecken und mit Rändelschraube 5 fixieren, hierbei muss die «Nase» des Rohres in die Aussparung des Sockels eintauchen (**Abb. A1**).
- Anlagebügel 3 je nach Instrument in die jeweilige Bohrung des Halterohres 2 einrasten lassen.

### Abb. B

- Aufnahmebügel 4 durch behutsames Biegen der SchallbechergroÙe des Instruments anpassen.

### Abb. C

- Die leichte Neigung des Einhängebügels entspricht der Form der meisten Instrumente und sorgt für einen noch besseren Sitz.

### Zubehör (nicht im Lieferumfang enthalten):

- Der Saxophonständer kann auch ausgestattet werden mit Kegeln für Flügelhorn, Trompete, Sopran-Saxophon und Klarinette.

Abb. A




Abb. B





Abb. C



Made in Germany

# 143 Saxophone Stand

- for Eb-Alto and Bb-Tenor Sax
- foldable
- flexible upper support arm
- extendable

## Instructions for Set-Up

### Illustration A

- Unfold legs from base tripod mechanism.
- Fit the tube 2 directly into the base tripod mechanism 1, making sure to position the small molded tab into the base opening (Illustration A1).
- Use screw knob 5 to tighten and secure the tube to the base tripod mechanism.
- Adjust T-shaped lower support arm bracket 3 to the desired height that compliments the design of your instrument. The T-shaped mechanism is then locked into the preshaped slots located along the front of the tube.

### Illustration B

- The upper support arm 4 can also be shaped by bending carefully to accommodate different size bells.


### Illustration C

- The upper support arm 4 is designed to hold the instrument at a particularly slanted angle. This ensures that the instrument is kept securely in place.


### Available accessories:

- Saxophone Stand can be used with peg holder and clarinet peg or with peg holder, adapter and pegs for trumpet, soprano sax or flugel horn.

### Illustration A



### Illustration B



### Illustration C

