


Spare parts list

107 Music stand

10700-000-55 - black

*Rev 03



Position	Description	Article No.	Quantity
1	Clamping element with pin R 6	01-86-620-55	1
2	Clamping element with pin R 7,5	01-86-630-55	1
3	Music stand bottom part	3-00-000-020	1
4	End cap	01-84-722-55	3
5	Clamping screw M6 x 11 mm	01-83-050-55	3
6	Screw connection of the music desk	3-00-000-005	1
7	Music desk complete	6-10700-1-55	1