

Holznotenpult 11701/06/07

Wooden Stand 11701/06/07

Aufstellanleitung

Zum Befestigen der FüÙe Standsäule 2 umkehren und Spannschrauben 8 (3 Stück) bis zum Anschlag in Standsäule eindrehen (Abb. A). FüÙe 1 (3 Stück) aufstecken (Abb. B). Exzenterhülsen 7 (3 Stück) so einsetzen, dass der Pfeil zur Standsäule zeigt. Durch Verdrehen der Exzenterhülsen - hierzu beigefügten Innensechskantschlüssel verwenden - Fussteile an Standsäule spannen (Abb. C).

Auszug 3 in Standsäule einschieben und mit Holzschraube in gewünschter Höhe festklemmen.

Gelenk 5 mit Kreuzschlitzschrauben 9 (2 Stück) an der Notenauflage 10 befestigen. Gummischeiben 4 (2 Stück) in Aussparungen am Auszug einlegen, Gelenk 5 darüber schieben und Notenauflage 10 mit Verschraubung 6 (2 Stück) in gewünschtem Neigungswinkel einstellen.

Assembly Instructions

TO ASSEMBLE FEET TO STAND, PLEASE TURN BASE COLUMN 2 DOWN AND SCREW THREADED LOCKING BOLTS 8 (3 PCS.) VERY TIGHT TO LIMIT STOP (PICTURE A). ATTACH FEET 1 (3 PCS./PICTURE B). INSERT LOCKING SCREWS 7 (3 PCS.) WITH ARROW POINTS TOWARDS COLUMN. USE ATTACHED ALLEN KEY TO FASTEN FEET TO COLUMN (PICTURE C).

INSERT EXTENSION COLUMN 3 INTO BASE COLUMN AND FASTEN WITH THE LOCKING NUT AT THE DESIRED HEIGHT.

ASSEMBLE WOODEN CONNECTING JOINT 5 TO DESK 10 WITH COUNTERSINK SCREWS 9 (2 PCS.).

PLACE RUBBER WASHER 4 (2 PCS.) IN PROVIDED SPACE OF EXTENSION COLUMN 3 AND SLIDE CONNECTING JOINT OVER. FASTEN DESK 10 WITH THE LOCKING NUT 6 (2 PCS.) AT DESIRED ANGLE.

